



Operating manual Digital Caliper with fractions Mechanic 150

MEASUREMENTS









FUNCTIONS

ON/OFF - turns the power completely on or off

mm/inch/F - switch between mm, inch and F by short pressing,

mm display in Metric mode inch display in inch mode in display in Fraction mode

ZERO - short pressing sets display to 0.00 at any position

Auto shut off display around 5 min, sliding blade to turn on the display when it shut down.

BATTERY REPLACEMENT / TROUBLE SHOOTING



Problem	Possible	Solution
	Cause	
Flashing Digits	Low	Replace Battery
	Voltage	
No Display	Low	Replace Battery
	Voltage	
No Display	Bad	Clean Battery
	Contact	
Erratic or	Internal	Remove Battery
Frozen Display	Error	Wait 1 Minute
		and Replace

WARRANTY DOESN'T EXTEND TO FOLLOWING CASES:

- 1. If the standard or serial product number will be changed, erased, removed or wil be unreadable.
- 2. Periodic maintenance, repair or changing parts as a result of their normal runout.
- 3. All adaptations and modifications with the purpose of improvement and expansion of normal sphere of product application, mentioned in the service instruction, without tentative written agreement of the expert provider.
- 4. Service by anyone other than an authorized service center.
- 5. Damage to products or parts caused by misuse, including, without limitation, misapplication or nrgligence of the terms of service instruction.
- 6. Power supply units, chargers, accessories, wearing parts.
- 7. Products, damaged from mishandling, faulty adjustment, maintenance with low-quality and non-standard materials, presence of any liquids and foreign objects inside the product.
- 8. Acts of God and/or actions of third persons.
- 9. In case of unwarranted repair till the end of warranty period because of damages during the operation of the product, it's transportation and storing, warranty doesn't resume.

For more information you can visit our website WWW.ADAINSTRUMENTS.COM or write the letter with your questions on info@adainstruments.com

WARRANTY CARD Certificate of acceptance and sale Name and model of the product Serial number date of sale Name of commercial organization _ _stamp of commercial organization Warranty period for the instrument explotation is 24 months after the date of original retail name and model of the instrument purchase. During this warranty period the owner of the product has the right for free repair of his instrument in case of manufacturing defects. Corresponds to ___ Warranty is valid only with original warranty card, fully and clear filled (stamp or mark of thr seller is obligatory). designation of standard and technical requirements Technical examination of instruments for fault identification which is under the warranty, is made only in the authorized service center. Data of issue _ In no event shall manufacturer be liable before the client for direct or consewuential damages, loss of profit or any other damage which occur in the result of the instrument outage. Stamp of quality control department The product is received in the state of operability, without any visible damages, in full completeness. It is tested in my presence. I have no complaints to the product quality. I am familiar with the conditions of garranty service and i agree. Price purchaser signature Sold name of commercial establishment Before operating you should read service instruction! If you have any questions about the warranty service Date of sale _ and technical support contact seller of this product